


1. Where applicable, screw spigot into body, using a suitable sealant to ensure the joint is watertight.
2. Position Body in roof deck and ensure that the outlet is accessible for pipework connection.
3. Install body such that flange is flush or sub-flush with roof deck. Ensure that body is fixed securely, either bonded or clamped to the deck if not cast in.
4. Refer to membrane manufacturer's instructions and prepare flange with suitable primer. Apply membrane, dressing over flange sufficiently into sump of body to enable it to be clamped. Position slotted membrane clamping collar and secure to body using supplied studs, nuts and washers.
5. Fit the adjustable grating frame onto the slotted membrane clamping collar, adjust height to suit application and lightly tighten pinch bolt to hold in position. (This pinch bolt is only intended to hold the grating assembly in the appropriate position prior to final fixing).
6. The grating/frame must be fully supported so as to prevent movement as appropriate to the intended application.
7. Fit the grating to frame with securing screws provided.

See also the general installation guidelines in Wade 'Roof Outlets' Brochure.

© 2011

ISS. No.	3		DRAWN	DC	16-2-11	TITLE 3400 SERIES GENERAL INSTALLATION DETAIL FOR WD2, WD3, WD70, 72, 73 SERIES ROOF OUTLETS	
C.N. No.	4940		CHECKED				
DATE	21/7/16		APPRVD.				
		Part Number 50910003			SCALE NTS	DRG. No. INSTAL 47	ISSUE No. 3

WADE INTERNATIONAL LTD., THIRD AVENUE, HALSTEAD, ESSEX, CO9 2SX.

TEL: 01787 475151 FAX: 01787 475579

e-mail: tech@wade.eu web site: www.wade.eu