


### Typical Installation Instructions

1. Fit cast iron body, complete with outlet spigot, through wall.
2. Dress membrane onto the body flange continuing a short distance into the body as shown.
3. Fit ductile iron membrane clamp collar such that it clamps the membrane all around forming a watertight seal. (note that for very thin and/or relatively hard membranes it may be necessary to use additional sealant to effect a seal)
4. Secure the stainless steel adaptor plate to the clamp collar.
5. Secure the grating onto the adaptor plate.

© 2011

ISS. No.		DRAWN	DC	16-2-11	TITLE GENERAL INSTALLATION DETAIL FOR WF052 - WF064 PARAPET OUTLETS		
C.N. No.		CHECKED					
DATE		APPRVD.					
	MATERIAL	50910037			SCALE NTS	DRG. No. <b>INSTAL 37</b>	ISSUE No. 3

WADE INTERNATIONAL LTD., THIRD AVENUE, HALSTEAD, ESSEX, CO9 2SX.

TEL: 01787 475151 FAX: 01787 475579

e-mail: tech@wade.eu website: www.wade.eu