


1. Where applicable, screw spigot into body, using a suitable sealant to ensure the joint is watertight.
2. Position Body in slab and ensure that the outlet is accessible for pipework connection.
3. Install body such that flange is flush or sub-flush with slab. Ensure that body is fixed securely, either bonded or clamped to the slab if not cast in.
4. Referring to cavity drain manufacturer's instructions, seal to gully if required. Position slotted membrane clamping collar and secure to body using supplied studs, nuts and washers.
5. Fit the C.D10 collar onto the height adjuster and fit into the slotted collar. Adjust the height to suit application and lightly tighten pinch bolt to hold in position. (This pinch bolt is only intended to hold the grating assembly in the appropriate position prior to final fixing).
6. Fit the grating/cover assembly into C.D10 collar and adjust height to suit FFL.
7. The grating/frame must be fully supported so as to prevent movement as appropriate to the intended application.

© 2011

ISS. No.	2		DRAWN	GJD	11-10-11	TITLE GENERAL INSTALLATION DETAIL FOR CAVITY DRAIN		
C.N. No.	4940		CHECKED					
DATE	21/7/16		APPRVD.					
		MATERIAL	50910005			SCALE	DRG. No.	ISSUE No.
						NTS	INSTAL 49	2

WADE INTERNATIONAL LTD., THIRD AVENUE, HALSTEAD, ESSEX, CO9 2SX.

TEL: 01787 475151 FAX: 01787 475579

e-mail: tech@wade.eu web site: www.wade.eu